

INSTRUCTIONS **#TGSWS TOURGAUGE® SWING WEIGHT SCALE** Zero Balance Beam Weight Shaft Butt Cradle Balance Beam Scale **Balance Weight** Total Weight Cradle Balance Beam **LEVEL BALANCE BEAM:** 1 Position Balance Weight at zero on Balance Beam Scale. Adjust Zero Balance Beam Weight until Balance Beam is level. **MEASURE SWING WEIGHT:** 2 Position butt of club in Shaft Butt Cradle and adjust Balance Weight until Balance Beam is level (See Fig. 1). Read corresponding swing weight. **MEASURE TOTAL WEIGHT:** 3 Balance club on Total Weight Cradle and adjust Balance Weight until Balance Beam is level. Read corresponding weight in ounces or grams.

Fig. 1